

RadStar Software Quick Start Guide

Quick Start Overview

- 1 Installing the USB / Serial Cable Driver
- 2 Installing the Data Capture Utility Program
- 3 Configuring the Data Capture Utility Program
- 4 Downloading Your Test Data to a PC
- 5 Exporting Your Test Data to a File

Installing the USB / Serial Cable Driver

IMPORTANT: Install the USB / Serial Cable Driver *before* you install the Utility Software.

1. Insert the Mini software CD (kit p/n 28262) that comes with the Cable Kit
 - a) For Windows XP:
Open the Folder "DRIVER". Open the Folder "WINDOWS". Double-click Setup.
 - b) For Windows VISTA and Windows 7:
Open the Folder "DRIVER". Open the Folder "VISTA". Double-click Setup.
2. After installation completes close all Windows and reboot your PC.

Installing the Data Capture Utility Program

1. Insert the large Data Capture Utility CD (p/n 28262) into your PC.
2. In the box that appears on screen, choose:
Windows 98 / 2000 / XP (middle box) or Windows Vista/7 (bottom box).
3. Follow the screen prompts. After installation, an icon will appear on your desktop.

Configuring the Data Capture Utility Program

After you are sure you have the correct software and cable driver installed, make the following settings:

- I. RadStar Model in the Setup of the RadStar Data Capture Utility
 1. On your computer, open the RadStar Data Capture Utility program.
 2. Click on Setup.
 3. Click on the correct RadStar Unit model number.

(continued on reverse)

RadStar Software Quick Start Guide (continued)

Downloading Your Test Data to a PC

1. Turn the RadStar keyswitch to [Keypad On] position.
2. Connect the PC cable to the Print Port on the RadStar and to your PC.
3. In the Data Capture Utility Program on your PC, click Download.
4. On the RadStar RS300 press the [Print] button.
5. On the RadStar RS500
 - a. Press the UP [^] button three times to display "Print Interval?".
 - b. Press the PLUS [+] button once to display "Y".
 - c. Press the UP [^] button.
6. On the RadStar RS800 press the [Next] button twice to display "Download?". Press the [Enter] button.

Exporting Your Test Data to a File

1. While your test data is still on the screen, click Export.
2. Choose the file type in which you would like to save your data. If you choose Excel, the Utility Program will start Microsoft Excel. The data will be exported into an Excel Workbook and a chart will be generated.
3. Type the test information (location, dates, technician, certification number, etc.) and save the file.

Version 3.3 of the Utility and the current cable driver are available for download on the AccuStar website at <http://www.accustarlabs.com>