

# QUICK START GUIDE

## BEFORE YOU BEGIN!

- Scan the QR code with your mobile phone or visit [accustarlabs.com/can4](https://accustarlabs.com/can4) to register device and fill out Data Form.
- Ensure that testing guidelines are followed. Scan the QR code for more information.
- **DO NOT** open test device until you are ready to start your test.
- **RECORD YOUR DEVICE NUMBER(S):** \_\_\_\_\_



KEEP FOR YOUR RECORD

## Start Test

PRIOR TO EXPIRATION DATE

1

### Test Instructions

Read the instructions thoroughly and scan the QR code or visit our website for more detailed instructions and supplementary videos.



2

### Record Start of Test Information

Once your device is registered and the start date is recorded on the online Data Form, you can begin your test.

3

### Begin the Test

Remove the vinyl tape and lid. Tape the lid to the bottom of the canister as shown below.



Leave the test in place for 2-4 days (48 - 96 hours).

## QUESTIONS? CALL US!

800-767-3703

You must have your device number(s) and zip code of the property tested.

**Details and videos online:**

 [accustarlabs.com/can4](https://accustarlabs.com/can4)



Expose for a duration of  
PICO CAN 400  
2-4 DAYS



## End Test

AFTER 2-4 DAYS

4

### End the Test

Remove the tape and lid from the bottom of the canister.



Replace the lid on the top of the canister and tape around the seam.

5

### Record End Date

Scan the QR code at top of page or visit [accustarlabs.com/can4](https://accustarlabs.com/can4) to complete the end of test information on the Data Form.



Place canister back into the return box. Double will have two canisters.

6

### Return Device to Laboratory

Using FedEx or UPS (USPS not recommended), return the device to the lab. We **MUST** receive your device within 7 days of the end of the test.



### Getting Your Report

You will receive your report via email. Same day results are available if the device is received by noon.

You may also view your report at [accustarlabs.com](https://accustarlabs.com), where you will find additional information and resources regarding your report.

## TIME SENSITIVE!

UPON COMPLETION, RETURN  
TEST AS SOON AS POSSIBLE.  
SEE REVERSE SIDE FOR DETAILS.